



INSTRUCTION MANUAL

Multi-Fit Flat Wiper Blade

Advanced Wiper Blade Design For Optimum Windscreen Contact



Thank you for choosing our product. If you have any questions or need assistance, feel free to reach out to our customer support team. We wish you clear visibility and safe travels on the road.

Note: Before Use

Before installing and using your new wiper blades, inspect the product thoroughly. Check for any visible damage or irregularities. If any issues are identified, do not proceed with installation. For

Table of Contents:

- Introduction
- Components
- Arm Type Compatibility
- How to Maintain
- Warnings
- Quick Reference Guide

1. Introduction:

This instruction manual provides essential information on product components, arm type compatibility, installation steps, maintenance guidelines, and important warnings for safe usage.

2. Components:

The product package includes:

- Wiper Blade x1
- 8 Connectors (MA2, MA6, MA5, MA7, MA9, MA11, M11, MA12) + Prefitted connector on the blade.
- Instruction Manual

Ensure all components are present and undamaged before proceeding with installation.

3. Arm Type Compatibility:

Our Car Wiper Blades are designed to fit the following arm types:

- MA11 - Slide Button Arm
- MA7 - 22mm Push Button Arm
- MA6 - 17mm Side Pin Arm
- MA6 - 22mm Side Pin Arm
- Pre-Fitted - 9mm Hook Arm
- M11 - Pinch Tab Arm
- MA2 - Euro Bayonet Arm
- MA9 - Notch Push Button Arm
- MA5 - 19mm Push Button Arm
- MA5 - Pinch Tab Button
- MA12 - TTL Arm

4. How to Maintain:

To prolong the life and performance of your wiper blades:

- Regularly inspect for wear, tears, or damage.
- Clean blades with a mild detergent and water solution.
- Check connectors for secure attachment and replace if damaged.
- Ensure wiper arms are free of corrosion or dirt.

5. Warnings:

- Handle wiper blades and connectors carefully to avoid pinching hands or fingers.
- When assembling components, apply force cautiously to prevent damage to wiper components.
- Keep hands clear of moving parts during installation and maintenance.
- Ensure the wiper lever is in the OFF position before lifting the windscreen wiper blades.
- Follow recommended procedures to prevent damage to wiper blades, arms, or the vehicle.



Arm Types

1. 9mm Hook



2. 22mm Push Button



3. 19mm Push Button



4. Notch Push Button



5. Pinch Tab



6. Pinch Tab Button



7. 22mm Side Pin



8. 17mm Side Pin



9. Euro Bayonet



10. Slide Button



11. TTL



Connector Types

1. MA6 Connector



2. M11 Connector



3. MA2 Connector



4. MA5 Connector



5. MA7 Connector



6. MA9 Connector



7. MA11 Connector



8. MA12 Connector



MA11 Connector & Slide Button Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA11. Push it firmly onto the metal wiper pin until it locks in place.	 Push back the plastic cap on the end of the wiper arm as far as it will go.	 Push the wiper blade and adaptor into the underside of the wiper arm.			 The plastic piece on top of the adaptor will fit into the hole in the wiper arm and the wiper will lock in place.
--	---	---	---	---	--	--	---

Scan for Video Instructions



MA7 Connector & 22mm Push Button Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA7. Push it firmly onto the metal wiper pin until it locks in place.	 Push the wiper blade into the end of the wiper arm.			 The button on the adaptor will lock into the square hole in the wiper arm.
--	---	--	---	--	--	--



MA6 Connector & 22mm Side Pin Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA6. Push it firmly onto the metal wiper pin until it locks in place.	 Hold the blade at a 90° angle to the wiper arm, and push the hole onto the metal pin.	 Rotate the wiper blade 90° to lock it into place.	 The metal bar on the wiper arm will fit snugly on the outside of the adaptor.	 The wiper blade is now secured in place.
--	---	--	---	---	---	--



MA6 Connector & 17mm Side Pin Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA6. Push it firmly onto the metal wiper pin until it locks in place.	 Hold the blade at a 90° angle to the wiper arm, and push the hole onto the metal pin.	 Rotate the wiper blade 90° to lock it into place.	 The metal bar on the wiper arm will fit snugly into the slot in the adaptor.	 The wiper blade is now secured in place.
--	---	--	---	---	--	--



Pre-fitted Connector & Standard Hook Arm

	 Pinch the two tabs on the front of the wiper adaptor and squeeze. Lift up the adaptor cover by 90°.	 Insert the wiper blade into the hook of the wiper arm. Push the wiper blade as far onto the arm as possible.	 Rotate the adaptor cover back down.			 The cover will click into place, securing the wiper arm.
--	---	--	---	--	--	--



MA12 Connector & TTL Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA12. Push it firmly onto the metal wiper pin until it locks in place.		 Insert the end of the plastic adaptor inside the end of the wiper arm.	 Rotate the wiper blade up until the wings on the adaptor lock in place.	 A click indicates that the blade is securely fastened.
--	---	---	--	--	---	--



MA2 Connector & Euro Bayonet Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA2. Push it firmly onto the metal wiper pin until it locks in place.		 Push the plastic adaptor onto the metal wiper arm as far as possible.		 A click indicates that the blade is securely fastened.
--	---	--	--	---	--	--

Scan for Video Instructions



MA9 Connector & Notched Push Button Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA9. Push it firmly onto the metal wiper pin until it locks in place.		 Push the wiper blade into the end of the wiper arm.		 The button on the adaptor will lock into the square hole in the wiper arm.
--	---	--	--	---	--	--



MA5 Connector & 19mm Push Button Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor MA5. Push it firmly onto the metal wiper pin until it locks in place.		 Push the wiper blade into the end of the wiper arm.		 The button on the adaptor will lock into the square hole in the wiper arm.
--	---	--	--	---	--	--



M11 & Pinch Tab Button Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor M11. Push it firmly onto the metal wiper pin until it locks in place.		 Pinch the two wings on the back of adaptor and raise the wiper gently inside the wiper arm.	 Push the wiper blade back, so the plastic tab locks over the metal arm.	 The two wings will click into place to secure the blade.
--	---	--	--	---	---	--



M11 Connector & Pinch Tab Arm

	 Rotate the prefitted adaptor forward. Pull firmly until it disengages from the blade, & discard it.	 Locate adaptor M11. Push it firmly onto the metal wiper pin until it locks in place.		 Place the hole in the end of the adaptor into the metal end of the wiper arm.	 Rotate the back of the wiper blade upwards.	 The two wings will click into place to secure the blade.
--	---	--	--	---	---	--



Additional Information:

For any additional information please visit our website: www.simply-brands.com. If you require more help with the instructions above please contact us on social@simply-brands.com and one of our colleagues will get back to you as soon as possible.